




Wolf Creek Dam Failure Inundation



Map Scale



Please Note

The flooded areas shown on this map are estimates for Emergency Evacuation Planning and Execution. Actual flooding heights may vary by +/- 15 feet.

Definition of Terms

River Mile -- The distance along the channel of the Cumberland River upstream from its mouth at the Ohio River.

Arrival Time -- Amount of time after an assumed event until water begins to rise at a location.

Rate of Rise -- Rate at which water will rise at a location after the arrival time.

Dam Failure -- Any condition resulting in the uncontrolled release of water other than over or through a controlled spillway or outlet works.

